



### Instructions:

1. Line out the central line of SPA and cover lift before in stallation,make the tow central lines coincide,the tolerances should be less than 5mm.
2. Install the rotation axis of SPA cover lift,fixed plate for locating sleeve,let the locating sleeve keep same level with SPA surface,the tolerances should be less than 3mm.
- 3.Lift the cover lift to the horizontal level,draw the damping spring of hydraulic-pressure to its utmost length,shown as drawing on the left.
- 4.Fix the rotation axis,push the fixed plate tipsily and then mount the fixed self-tapping screws.
- 5.After installation,testing it 3 to 5 times repeatedly.If the tests are ok,it can be put into use.Others instructions refer to the Installation of Cover Lift.